



# Receiver Programming

These instructions are for programming Receivers to a new Transmitter. Please be sure to read the entire instructions before programming.

**NOTE:** These instructions are only valid for receivers with an “X” in the part number.

## Contents

|                                    |          |
|------------------------------------|----------|
| <b>STANDARD TRANSMITTER .....</b>  | <b>2</b> |
| <b>LONG RANGE TRANSMITTER.....</b> | <b>5</b> |

## STANDARD TRANSMITTER OPENING THE TRANSMITTER

- 1) Your new transmitter should look like this: (front)




- (back)




- 2) Flip the transmitter over and remove the ring clip.



- 3) Remove the Philips head screw and gently pry the plastic case open.




- 4) Remove the circuit board but leave the battery in place.




# STANDARD TRANSMITTER

## PROGRAMMING

- 1) Disconnect power to the Receiver.
- 2) Have the new Transmitter (with battery) ready. (test by pushing a button and the red LED should turn on.
- 3) Apply power to the Receiver and continue to the next step within **10 seconds**.



- 4) Push the bottom button on the receiver for **3 seconds**.
- 5) Listen for a long beep from the receiver indicating that the transmitter's code has been saved.
- 6) Disconnect the power to the Receiver for a few seconds.
- 7) Connect power to the Receiver and test new Transmitter by pushing the Lock and then




the Unlock buttons.

## STANDARD TRANSMITTER

### ERASE RECEIVER

- 1) The Receiver's memory can be entirely erased of all transmitter codes.
- 2) Disconnect power to the Receiver for a few seconds and reconnect.




- 3) Press the Erase button on the transmitter for 5 seconds.
- 4) Release the button when you hear 8 short beeps from the Receiver indicating that all codes have been erased.

## LONG RANGE TRANSMITTER

### OPENING THE LONG RANGE TRANSMITTER



1) Transmitter should look like this:




- 2) Remove the three screws on the back cover
- 3) Split the front cover from the back cover.
- 4) Remove the circuit board and battery. Leave battery attached to circuit board.
- 5) After programming, assemble transmitter in reverse order.


# LONG RANGE TRANSMITTER

## PROGRAMMING (4 internal buttons)

- 1) Disconnect power to the Receiver.
- 2) Have the new Transmitter (with battery) ready. (test by pushing a button and the red LED should turn on.
- 3) Apply power to the Receiver and continue to the next step within **10 seconds**.



- 4) Push the bottom button on the receiver for **3 seconds**.
- 5) Listen for a long beep from the receiver indicating that the transmitter's code has been saved.
- 6) Disconnect the power to the Receiver for a few seconds.
- 7) Connect power to the Receiver and test new Transmitter by pushing the Lock and then




the Unlock buttons.

# LONG RANGE TRANSMITTER

## PROGRAMMING (2 internal buttons)


- 1) Disconnect power to the Receiver.
- 2) Have the new Transmitter (with battery) ready. (test by pushing a button and the red LED should turn on).
- 3) Apply power to the Receiver and continue to the next step within **10 seconds**.



Jumper wire or paperclip

- 4) Short out the two bottom right pads with a jumper wire or paperclip for **3 seconds**. The LED will illuminate.
- 5) Remove the jumper when there is a long beep from the receiver indicating that the transmitter's code has been saved.
- 6) Disconnect the power to the Receiver for a few seconds.
- 7) Connect power to the Receiver and test new Transmitter by pushing the Lock and then


the Unlock buttons.



# LONG RANGE TRANSMITTER

## ERASE RECEIVER

- 1) The Receiver's memory can be entirely erased of all transmitter codes.
- 2) Disconnect power to the Receiver for a few seconds and reconnect.



- 3) Short out the two pads with a jumper wire or paperclip for 5 seconds. The LED will illuminate.
- 4) Remove the jumper when you hear 8 short beeps from the Receiver indicating that all codes have been erased.